

# BL-5401

## Coach's Button biCoder™

### Installation Guide

#### Installation Instructions

1. Power off the two-wire when installing devices. Leave 24 to 36 inches of slack on the two-wire to allow for easy installation and maintenance.
2. Mount the coach's button to a vertical surface with four screws and suitable wall anchors.
3. Connect the red and black wires from the biCoder to the corresponding red and black wires on the two-wire. It is critical that polarity be maintained.
4. Refer to the controller's user manual for configuration instructions.

