

**IMPORTANT!**

Expansion modules are for BaseStation 1000 controllers manufactured before January 1, 2018

# BL-1000MEXP Installation Guide


The BL-1000MEXP-25 & -50 expansion modules increase the total number of supported devices. The BL-1000MEXP-BM expansion module provides full support for BaseManager.

1. Disconnect power to the **BaseStation 1000**.
2. Identify the expansion slots on the back of the BaseStation 1000 display.
3. Carefully Insert the **BL-1000MEXP Expansion Module** into either expansion slot as shown.
4. Re-connect power to the **BaseStation 1000**.
5. Verify that the installation was successful by pressing the **System Setup** button on the controller. Select the **Expansion Modules** option, and review the information on the screen.




```

Expansion Modules
EXPANSION MODULE SLOT 1
MODULE FOUND.....YES
DEVICE VERSION.....1.1
TYPE.....BL-1000MEXP-50
EXPANSION MODULE SLOT 2
MODULE FOUND.....NO
  
```



Expansion Slots  
Back of BaseStation 1000 Display



BL-1000MEXP Installed  
Back of BaseStation 1000 Display

1-866-294-5847

Rev12.4.2017

www.baselinesystems.com

## BL-1000MEXP Installation Guide

Total Supported Devices	Base Model	With the BL-1000MEXP-25	With the BL-1000MEXP-50
Zones	50	75	100
Programs	20	30	40
Moisture Sensors	10	15	20
Water Sources	1	2	3
Event Switches	3	5	7



The **BL-1000MEXP-BM** expansion module provides full support for BaseManager.

